



使用手册 User manual





目录

1 欢迎	4
产品特点	4
2 重要须知	5
2.1 安全	5
2.2 听力保护	5
3 您的录音笔	6
3.1 供货范围	6
概览	6
4 开始使用	7
4.1 开 / 关机	7
5 主界面功能	8
5.1 标准	8
5.2 备忘	9

6 边录边写	10
7 文件	11
8 用户	12
9 充电方法	13
9.1 连接电脑	13
10 常见问题	14
10.1 无法启动	14
10.2 转写不出来	14
10.3 机器死机	14
技术参数	15
11.1 存储器	15
11.2 尺寸和重量	15
11.3 系统要求	15
11.4 录音	15
11.5 运行条件	15

1 欢迎

www.philips.com

产品特点

-
- WAV 96kHz, 16 PCM
-
-
-
- SD
- Type-C
- MP

2 重要须知

2.1 安全



小心


-
- / / / /
APP

2.2 听力保护


-
-
-

3 您的录音笔

3.1 供货范围：



3.2 概览：



- ① 音量“+”键
- ③ 电源键
- ⑤ 咪头
- ⑦ 喇叭
- ⑨ 录音键

- ② 音量“-”键
- ④ 内存卡/SIM卡
- ⑥ 工作指示灯
- ⑧ USB

4 开始使用

4.1 开 / 关机



3 4



5 主界面功能




6

5.1 标准



6 边录边写



7 文件

中文



1



2

3

4

8 用户



WIFI

10 常见问题

www.philips.com/support

10.1 无法启动

10.2 转写不出来

10.3 机器死机

10

技术参数

11.1 存储器

EMMC
(PC)

WiFi

11.2 尺寸和重量

x x 112 x 52 x 11.5 (mm)
105 (g)

11.3 系统要求

Windows 7/8/10/Vista/2000, Mac OS X, Linux
USB

11.4 录音

1411.2Kbps, 44.1KHz-16bit
3072Kbps, 96KHz-16bit
705.6Kbps, 44.1KHz-16bit
1536Kbps, 48KHz-16bit
1411.2Kbps, 44.1KHz-16bit
256Kbps, 16KHz-16bit

11.5 运行条件

5° C- 45° C
10% - 90%

Content

1 Welcome	17
1.1 Product features	17
2 Important Notes	18
2.1 Safety	18
2.2 Hearing protection	18
3 Your Voice Recorder	19
3.1 What's in the box	19
3.2 Overview	19
4 Start Using	20
4.1 Switch on/off	20
5 Functions on Main Screen	21
5.1 Standard recording	21
5.2 Memo	22
6 Voice-to-text	23
7 Files	24

8 User	25
9 Charging	26
9.1 PC connection	26
10 FAQs	27
10.1 Failure to start	27
10.2 Failure to transcribe	27
10.3 Dead halt	27
11 Technical Parameters	28
11.1 Memory	28
11.2 Dimensions and weight	28
11.3 System requirements	28
11.4 Recording	28
11.5 Operating conditions	28

I Welcome

Welcome to the world of Philips! We are honored by your choice and purchase of Philips' products. You can have Philips' comprehensive technical supports from our website, e.g. user's manuals, software downloading and warranty information etc.

www.philips.com

1.1 Product features

- Built-in high-performance coding and decoding chip;
- Recording in the common WAV format, supporting 96KHz, 16-digit PCM recording;
- Supporting the conversion of audio files into texts;
- Supporting WIFI;
- Supporting file sharing;
- Supporting expanded SD cards;
- Using high-speed Type-C to access audio files and data quickly;
- Ensuring maximum compatibility as an MTP storage device.

2 Important Notes

2.1 Safety

Do not expose this unit to water and moisture to avoid short circuit.

Do not expose this unit to any heating device or direct sunlight.

Do not pinch the cable, especially at the plug.



- Special Announcement: Before using the product, please read the Manual carefully. The Company shall not be held liable for any data loss due to incorrect manual operation or force majeure. We specially recommend that users make additional copies of the files in the device.
- Images are for reference only. Philips reserves the right to change the color/appearance/design/parameters/product functions without prior notice.


2.2 Hearing protection

Please observe the following provisions when using the earphone:


- Adjust it to an appropriate volume, and do not use it for an extended period of time.
- In particular, do not set the volume out of the tolerable range of the ear.
- Do not set the volume beyond ambient sounds. Please use the earphone carefully or suspend using it in a dangerous environment.
- Do not use the earphone while driving, cycling or skating, or else a traffic accident may occur, and a violation of the applicable laws and regulations may be committed.

3 Your Voice Recorder

3.1 What's in the box:



3.2 Overview:



English

- ① Volume "+" key
- ② Volume "-" key
- ③ Power key
- ④ Memory card / SIM card
- ⑤ Microphone
- ⑥ Work indicator lamp
- ⑦ Speaker
- ⑧ USB
- ⑨ Record key

4 Start Using

4.1 Switch on/off



5 Functions on Main Screen

The main screen menu includes various recording mode. The reference screen is as follows:


The main screen menu has 6 functional modules, which are standard, meeting, interview, speech, class and memo.

- Standard: used for recording in ordinary places
- Meeting: used for recording at conferences
- Interview: used to record dialogues of interviewees
- Speech: used to record speeches
- Class: used for recording in classrooms
- Memo: used to record events

Click on the search bar to switch quickly to the file screen, and enter a keyword to search for your desired file quickly. In the main interface, file list or user list interface, press the record button of device to directly enter the recording.

5.1 Standard recording

Click on "Standard" in the main screen menu to enter the following standard recording screen:




In the recording state, click the "●" to pause the recording, click again to cancel the pause and continue recording, then click the "Save" on the right to save the recording. Click on "◀" to return to the main screen. To mark an important

thing during recording, click on “Mark” at the corresponding time point to mark the current time; during file playback, select “View Mark” to go to the marked time point for playback.

Meeting, interview, speech, class recording operation please refer to 5.1 standard recording.


5.2 Memo

Click on “Memo” in the main screen menu to enter the following memo recording screen:



The memo is easier for saving, and applies to event recording. After entering the memo recording screen, hold down

“+” to pop up a voice recognition box and start voice recognition, and click on “✓” to end voice recognition and save. Click on the saved file to view and edit the text, and click on “🔊” to play the audio file, as shown below:




6 Voice-to-text

Click on “Text” in the lower part of the main screen. The reference screen is as follows:




Click on “▶” on the screen of Record while writing, to sync transcribe being recorded. The screen after transcription is shown as follows:




Click on “Save” in the lower right corner to save it. Click on “☰” in the upper right corner to pop up an “turn on smart translation” box, where you can switch on / off the translation, and select your desired language.

7 Files

Click on “Files” in the lower part of the main screen. The reference screen is as follows:




- (1) Files recorded on the main screen and those generated after concurrent recording and writing are stored here, and divided into “Record file” and “Voice-to-text file”. Click on them to open and view them, recording screen as shown below:



- (2) Click on “▶” on the playback screen to play files, and click on “☰” in the upper right corner to select “Audio transliteration”, “Edit text”, “Cut audio” and “Synthesized audio”.
- (3) Click on “Audio transliteration” to select your desired language for transcription; after transcription, click on “Save”; click on “Edit text” to edit the transcribed text; click on “Cut audio” to clip an audio file; click “Synthesized audio” to synthesize the audio.
- (4) If an audio file has a mark, select “View Mark” and click on the desired marked time point to go to that time point for playback.

8 User

Click on “User” in the lower part of the main screen. The reference screen is as follows:



The user interface includes such as My cloud disk, WIFI connection, Personal hotspot, Bluetooth settings, Language, Screen brightness, Privacy and security, etc.

9 Charging

Use a USB data cable to connect this unit to a PC.
Please use the dedicated charger for charging. The indicator will be illuminated during charging, and go out after full charging.

9.1 PC connection

As a storage device, the recorder may be connected to a PC with a USB data cable for file storage, backup and moving without installing any software.



- In case that the document is moved into or out of the recorder, please do not disconnect the recorder away from the computer; otherwise, the document may be damaged.

10 FAQs

Here, we list the answers to FAQs to help you solve simple problems regarding this intelligent recorder. If the fault still cannot be eliminated, please consult the dealer or visit our official website: www.philips.com/support.

10.1 Failure to start

The battery has run out. Please charge it timely.

10.2 Failure to transcribe

Check if the network signal is normal.

10.3 Dead halt

Hold down the power key for 10 seconds to reset it.

11 Technical Parameters

11.1 Memory

Built-in storage space
Built-in memory type: EMMC
Mobile memory (PC): Yes
Storage card: Yes
WIFI: Yes

11.2 Dimensions and weight

Width × height × depth: 112 × 52 × 11.5 (mm)
Weight (including battery): 105 (g)

11.3 System requirements

Operating system: Windows 7/8/10/Vista/2000, Mac OS X,
Linux
Interface: USB

11.4 Recording

Standard recording: 1411.2Kbps, 44.1KHz-16bit
Meeting recording: 3072Kbps, 96KHz-16bit
Interview recording: 705.6Kbps, 44.1KHz-16bit
Speech recording: 1536Kbps, 48KHz-16bit
Class recording: 1411.2Kbps, 44.1KHz-16bit
Memo recording: 256Kbps, 16KHz-16bit

11.5 Operating conditions

Temperature: 5°C-45°C
Air humidity: 10%-90%, non-condensing

Date of purchase



